

YTÜ

**YILDIZ TECHNICAL
UNIVERSITY**

Department Of Mechatronic Engineering

MKT3434 Machine Learning

HW2

Instructor

Ertuğrul Bayraktar

Emirhan AK 210A020

İstanbul 2025

Introduction

This project extends a machine learning GUI with the integration of several key methods, including PCA (with explained variance plotting and CSV export), t-SNE and UMAP (with configurable dimensionality and interactive 2D/3D visualization), LDA for supervised reduction, K-Means clustering with inertia and silhouette score metrics, the Elbow Method for optimal k selection, and K-Fold Cross-Validation with mean and standard deviation reporting. Additionally, UMAP and t-SNE results can be exported, and all components support user-adjustable parameters from the interface.

Principal Component Analysis (PCA)

PCA is a linear dimensionality reduction technique that projects high-dimensional data into a lower-dimensional space by maximizing variance along orthogonal axes. It is commonly used for data compression, noise reduction, and visualization.

GUI Integration

- The GUI allows the user to select the number of principal components (n_components) via a spinbox.
- A cumulative explained variance plot is generated to visualize how much information is retained.




Figure 1,2 : Cumulative Explained Variance plot of Arduino Sensor Values and PCA Group

PCA Visualization

After reduction, the first two(three for 3D) principal components are used to visualize the dataset in 2D,3D.






Figure 3,4 = PCA visualization 2D,3D

Sensor Data Compression via PCA

I also added the option to save the PCA applied version as CSV. To evaluate the impact of PCA on real sensor data (e.g., EMG), two separate training runs were conducted:



✓ With PCA:



✗ Without PCA:

Metric	With PCA	Without PCA
Input Feature Size	40 components	561 raw features
Training Time	1.03 seconds	8.02 seconds
Accuracy	73.09%	: 88.81%

Although the accuracy decreased slightly when using PCA, the training time was nearly halved and the feature dimensionality was significantly reduced. This demonstrates that PCA offers a valuable trade-off for sensor data pipelines, where reducing computational cost is often more critical than achieving the absolute highest accuracy.

t-SNE – Nonlinear Dimensionality Reduction & Visualization

The GUI includes full support for **t-SNE**, a nonlinear technique used to visualize high-dimensional data in 2D or 3D space. The user can configure:

- perplexity (controls local vs global structure)
- n_components (2D or 3D)

Once the transformation is applied:

- An interactive **Plotly** scatter plot is generated
- **Silhouette score** is computed and shown in the chart title




Figure 7: t-SNE settings Group




Figure 8 : t-SNE Projection

UMAP – Flexible Dimensionality Reduction (Visual & Model-Ready)

For Faster Alternative to tsne

UMAP offers both visualization and data compression capabilities:

- Parameters `n_neighbors`, `min_dist`, and `n_components` are fully configurable
- The user can apply UMAP and:
 - **Visualize results in 2D or 3D**
 - **Export the reduced feature set as CSV**

This makes UMAP suitable for use both in exploratory data analysis and as input to machine learning models.




Figure 9: UMAP group




Figure 10: Umap Projection

LDA – Supervised Dimensionality Reduction

Linear Discriminant Analysis (LDA) was added as a supervised method that uses class labels to find projection axes that maximize inter-class separation.

In the GUI:

- LDA is applied in 2D (up to `n_classes - 1` components)
- An interactive scatter plot is generated with class-colored clusters
- Silhouette score is calculated and displayed



Figure11: LDA Projection

K-Means Clustering + Evaluation Metrics

K-Means clustering is fully integrated with:

- Configurable `n_clusters`, `n_init`, and `max_iter`
- Clustering is visualized in 2D using PCA projection
- Both **inertia** (compactness) and **silhouette score** (cluster separation) are computed and shown




Figure 12: K-Means Group




Figure 13,14: Elbow method for optimal k and with optimal k K-Means Clustering

Based on the Elbow Method plot, $k = 3$ was selected as the optimal cluster number, as it represents the point where the rate of inertia decrease significantly slows down.

K-Fold Cross-Validation – Robust Model Evaluation

To ensure robust performance estimation:

- The user selects the number of folds (k)
- Metrics supported include: **Accuracy**, **MSE**, **RMSE**, **MAE**
- The GUI displays both:
 - **Mean score across folds**
 - **Standard deviation** (for performance consistency)




Figure 15: K-Fold parameters and check button added to Data Management




Figure 16: k-fold applied to Iris Dataset

Raw Signal Feature Extraction + Undersampling

The system supports working with time-domain signals (e.g., EMG data):

- Data is segmented based on a configurable segment size
- Statistical features are extracted per segment:
 - mean, std, min, max, rms(EMG data has 8 channel if we extract the feature, $8 \times 5 = 40$ feature)
- **Undersampling** can be applied to balance the dataset before segmentation
- The resulting feature set is saved as a CSV file




Figure 17: when click the extract features we select raw data. After that dataset with extracting feature can be saved

```
1 "time","channel1","channel2","channel3","channel4","channel5","channel6","channel7","channel8","class","label"
2 1,1e-05,-2e-05,-1e-05,-3e-05,0,-1e-05,0,-1e-05,0,"1"
3 5,1e-05,-2e-05,-1e-05,-3e-05,0,-1e-05,0,-1e-05,0,"1"
4 6,-1e-05,1e-05,2e-05,0,1e-05,-2e-05,-1e-05,1e-05,0,"1"
```

Figure 18: raw data

```
1 channel1_mean,channel1_std,channel1_min,channel1_max,channel1_rms,channel2_mean,channel2_std,channel2_min,channel2_max,channel2_rms
2 2.9499999999999995e-05,0.00012379317428679176,-0.00022,0.0004,0.00012725957724273642,-1.8e-05,5.608921464952063e-05,-0.00021,4e-05,0.00012379317428679176
3 -3.5000000000000001e-06,0.00012264888911033806,-0.00047,0.00022,0.00012269881825021788,-5.5000000000000001e-06,3.814118508908709e-06,0.00012264888911033806,-0.00047,0.00022,0.00012269881825021788
```

Figure 19: Extracted feature data









Figure 20: EMG data Train completed with accuracy %94.89

Manual Eigen Decomposition for 1D Projection



GUI Screenshots



Additionally, a Random Forest Regressor was integrated into the GUI. Compared to other regression models, it produced significantly higher R^2 scores